

Squeegeeing:

The Palm Technique: Avoiding Adhesive Lines:

It is recommended that moderate recessed areas be applied first with an application glove then with a flat squeegee. This can, in most cases, be done without the use of heat which means the film will not be overstretched. By applying the recessed areas first with an application glove, the film is applied to the entire section in one stroke which avoids having to work into these areas in multiple squeegee strokes. Using squeegee strokes to apply the film into recessed areas can create adhesive lines.



Once the recessed area has been applied with the application glove, the flat section can be applied in overlapping squeegee strokes. The RS feature will keep the film away from the surface so there should be no bubbles.



Squeegee Technique:

How to hold: The squeegee should be held with the thumb on one side and the remaining fingers on the other side. The position of the fingers will shift depending on the size and surface type of the area being applied. The squeegee should be held firmly so the proper force can be applied onto the film. The adhesive is pressure activated, so the harder the force placed on the film, the better.