



For empty edges that are high grab points or white/yellow/red painted vehicles, its best for the installer to cut on the solid side of the gap. This will create around ¼ inch of material that will wrap around the empty edge. This is called Solid Cut #1. Be sure to heat and soften the angles found on body lines first to avoid any wrinkles when sealing the film onto inside portion of the body.

