

Solid Cuts:

For color change wraps on vehicles that are not painted black, installers will have to work the film deeper into the body of the vehicle. This means they will often be cutting directly on the paint. To remove the excess film, using cutting tape is required in order to avoid cutting the clear coat or paint. Its key to run the cutting tape along body lines in order to get professional finishes.



9 - Layout

Placement and alignment of the digital full print graphics is extremely important. Poorly placed or crooked graphics will make the install look bad no matter how meticulous the installation. Learning how to lay out the panels and align them precisely is key for professional level installations.

Printed Layout: A printed layout should come with the digital full print graphics. This printed layout is a guideline for the installer to use when laying out the panels. It is very important to remember that this printed layout is not an exact reference but a rough estimation. What will end up on the vehicle will not necessarily match the printed layout. This is due to several reasons:

- The design/printed layout is a 2-dimensional design made for a 3-dimensional object
- The vehicle may be a different year or model
- An error in the sizing of the graphics occurred during the printing process